# RTS

EPAP-32 Expansion Program Assignment Panel

Installation

The EPAP-32 Expansion Program Assignment Panel connects to a PAP-32 panel as shown in the diagram to the right. The EPAP-32 functions like an extension of the PAP-32 panel. Consult your PAP-32 manual for additional information concerning operation and use of the panel.

PAP-32 Rear Panel

RJ-45 Cable (Provided)

EPAP-32 Rear Panel

Specifications

AC Supply

AC Input:.........................100-240 VAC, 50/60 Hz

Power Consumption

Nominal: .... 0.08 A

Maximum: .... 0.10 A

Maximum Volt Amp: .... 18 VA

General

Color .... Grey or Black

Height ....3.5" (88.9 mm)

Width ....19" (482.6mm)

The specification information is preliminary and is subject to change without notification. Brand names mentioned are the property of their respective companies.

RTS
www.rtsintercoms.com