## **KP 32 CLD GPIO Option Card**

## **Installation Instructions**

To install the GPIO option card in to the KP 32 CLD, do the following:

1. Using a Phillips head screw driver, remove the **nine (9) screws** securing the blank plate in place on the rear of unit (see Figure 1 for screw locations).




FIGURE 1. Screw Removal Locations

2. Remove the blank plate.




FIGURE 2. GPIO Connector on the KP 32 CLD board

LIT000440000 Rev A 9/2009




FIGURE 3. GPIO Option Card connected to the KP 32 CLD

3. Connect the GPIO Option Card cable to the GPIO connector (see Figure 2) within the KP 32 CLD.

**IMPORTANT:** Connect Pin 1 (red wire) on the furthest left side of the connector as shown in Figure 3. Pin 1 is also designated by the 1 on the KP 32 CLD board, as seen in Figure 2, Detail A.

**4.** Align the **GPIO Option Card** with the screw holes on the KP 32 CLD.




FIGURE 4. Replacing the GPIO Option card in the KP 32 CLD

**5.** Replace the **screws** in the appropriate holes (see Figure 1).

For information about the GPIO option card features, see the KP 32 CLD User Manual (93507858000).