

# Two-Wire Intercom

## Balanced System

Audiocom®

1  
2  
3



DC Return "COM"

Audio CH #1+Call Signal+Mic Off+Power

Audio CH #1+Call Signal+Mic Off+Power

## Unbalanced System

RTS®

Clear-Com®


Audiocom®

Secondary Config.

COM 1

Audio CH #1+Call Signal+Mic Off+Power 2


Audio CH #2+Call Signal+Mic Off 3



Com 1

Power 2

Audio/DC Call 3



unbal